

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

DANGER - Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

1. **ALWAYS UNPLUG APPLIANCE IMMEDIATELY AFTER USING.**
2. Do not use while bathing or in a shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into water or other liquid.
5. If an appliance falls into water, unplug it immediately. **Do not reach into the water.**

WARNING - To reduce the risk of burns, electrocution, fire, or injury to persons:

1. This appliance should never be left unattended when plugged in.
2. This appliance should not be used by, on, or near children or individuals with certain disabilities.
3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.

4. Do not use an extension cord to operate appliance.
5. **Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.**
6. Keep the cord away from heated surfaces.
7. Do not pull, twist, or wrap line cord around appliance, even during storage.
8. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
9. Never use while sleeping.
10. Never drop or insert any object into any opening.
11. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
12. This straightener is hot when in use. Do not let heated surfaces touch eyes or bare skin.
13. **Do not place the heated straightener directly on any surface or on the appliance power cord while it is hot or plugged in.**
14. Before plugging in read the information about dual voltage contained in the instruction section of this manual.
15. Do not attempt to touch the housing of your appliance near the straightening plates as it is hot when in use.
16. Do not touch hot surfaces of the appliance. Use the handles or knobs.
17. Do not use with a voltage converter.

SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

This straightening iron is intended for household use. This unit is designed to operate at 120/240 volts AC. Use on Alternating Current (50/60 hertz) only.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

DUAL VOLTAGE

This straightening iron will automatically adjust to the proper voltage. Use an adapter plug with correct configuration, prior to use in outlet.

STRAIGHTENING BASICS

Plug the straightening iron cord into any household outlet (120V/240V). Press power On/Off button. Red light will blink while heating up. When straightener is ready to use, red light will remain steady. The iron will heat up very quickly. To turn off, press to On/Off button again. Red light will go off. Never leave your straightening iron on and unattended. However, should you fail to turn the unit off, it will shut itself off automatically within 60 minutes.

WARNING: The straightening iron's ceramic-coated plates will get very hot within a few seconds and should not be placed in contact with the skin after the straightening iron has been turned on.

Start with a hair section that is 2" wide and no more than 1/2" thick. Open the iron and place a hair section between the two hot plates, close to the scalp. Close plates over hair by firmly squeezing the handles together. While maintaining the tension, slowly pull the unit down along the hair section toward the end of hair. At the end of hair section, release the pressure on the handle and allow the hair to slide out. Repeat process on additional sections of hair until you achieve the hair style you desire. It may be necessary to repeat process on certain areas, depending on the texture of your hair.

Some experience is necessary when learning to use this straightening iron. After using the iron several times, you will learn the ideal way to straighten and style your hair easily.

NOTE: Please refer to the temperature setting guide for heat settings.

COMFORTABLE GEL GRIPS™ HANDLE

The Comfortable Gel Grips™ handle is cushioned to make styling easier, less tiring on your hands.

USING INSTANT HEAT, THE 30 TEMPERATURE SETTINGS & UNIFORM HEAT RECOVERY SYSTEM

This straightening iron features Conair's Instant Heat™ technology, so it quickly heats up to the temperature you've selected for your hair type.

There are 30 temperature settings to choose from, so you can adjust the temperature for every type of hair, from the finest to the curliest and most resistant.

Temperature Setting Guide

TEMP. CONTROL	HAIR TYPE
Low 1-8	Delicate, thin, easy-to-straighten hair
Medium 9-14	Average to thick or treated hair
Med-High 15-20	Thick or wavy hair
High 21-25	Hard-to-straighten hair
Maximum 26-30	Coarse, very resistant hair

1. ALWAYS UNPLUG APPLIANCE IMMEDIATELY AFTER USING.	2. Do not use while bathing or in a shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.	4. Do not place in, or drop into water or other liquid.
5. If an appliance falls into water, unplug it immediately. Do not reach into the water.	6. Keep the cord away from heated surfaces.
6. Never use while sleeping.	7. Do not pull, twist, or wrap line cord around appliance, even during storage.
7. Do not drop or insert any object into any opening.	8. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
8. Never use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.	9. Never use while sleeping.
9. Do not place the heated straightener directly on any surface or on the appliance power cord while it is hot or plugged in.	10. Never drop or insert any object into any opening.
10. Before plugging in read the information about dual voltage contained in the instruction section of this manual.	11. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
11. Do not attempt to touch the housing of your appliance near the straightening plates as it is hot when in use.	12. This straightener is hot when in use. Do not let heated surfaces touch eyes or bare skin.
12. Do not touch hot surfaces of the appliance. Use the handles or knobs.	13. Do not place the heated straightener directly on any surface or on the appliance power cord while it is hot or plugged in.
13. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.	14. Do not use an extension cord to operate appliance.

GUÍA DE TEMPERATURA

Este aparato tiene capacidad para usar 30 niveles de temperatura. Su plancha también ofrece 30 niveles de resistencia. Selecione la temperatura deseada girando el selector de temperatura. Los niveles de temperatura ofrecen una gama completa de calor y mantenerse estable durante el uso. Los niveles de resistencia ofrecen una gama completa de calor y mantenerse estable durante el uso.

Su plancha también ofrece 30 niveles de resistencia. Seleccione la temperatura deseada girando el selector de temperatura. Los niveles de resistencia ofrecen una gama completa de calor y mantenerse estable durante el uso.

CONSERVADORA ALTA DE 120V/240V

CONSERVADORA ALTA DE 120V

